

## Emerson Installation Instructions

- 1) Locate White Compressor wire on the Compressor and follow to electrical box Run Capacitor “**C**” terminal. Disconnect and splice White wire connection to the Brown RVAC soft start wire.
- 2) Connect Red RVAC soft start wire to the location of the previous White Compressor wire terminal on the Run Capacitor “**C**” terminal.
- 3) Disconnect the Red Compressor wire from the “**H**” terminal on the Run Capacitor. Connect Blue RVAC soft start wire on that terminal. Reconnect the Red Compressor wire onto the Piggyback connector of the Blue RVAC soft start wire.
- 4) **IF** you see a second Red wire next to the Red Compressor wire, disconnect it and seal end with electrical tape.
- 5) Locate the 3<sup>rd</sup> wire coming out of the Compressor overload switch (may be Blue or Black), route and 3-way splice the final Black soft start wire to a convenient location along the Compressor’s (Blue or Black) wire.