

Carrier RV Air Conditioner

CAUTION!
SHOCK HAZARD!
Disconnect power
supply before servicing
any electrical component.

Legend:
S = Start
C = Common
H = Hermetic
R = Run
OL = Overload Switch
F = Fan
(Disconnected)
.....

