

Dometic Cool Cat

**CAUTION!
SHOCK HAZARD!**
Disconnect power supply before servicing any electrical component.

Legend:
S = Start
C = Common
H = Hermetic
R = Run
OL = Overload Switch
F = Fan

(Disconnected)
.....

