

Dometic Penguin I and II

**CAUTION!
SHOCK HAZARD!**
Disconnect power supply before servicing any electrical component.



Legend:

- S = Start
- C = Common
- H = Hermetic
- R = Run
- OL = Overload Switch
- F = Fan

(Disconnected)
.....

