


LG RV AC Relay



Legend:
S = Start
C = Common
H = Hermetic
R = Run
OL = Overload Switch
F = Fan

(Disconnected)
.....



CAUTION!
SHOCK HAZARD!
Disconnect power supply before servicing any electrical component.